


hohem

# RS01

Selfie Stick Tripod &  
Wireless Remote Kit

User Manual V1.0

# Remote Control



## ① Power Button

ON: Power On OFF: Power Off

## ② Shutter Button

(Make sure the app connect to the gimbal successful)

Single Press: Take photo, Start/End video  
Double Press: Switch the photo and video modes

Triple Press: Switch the front and rear cameras(Only available in the app)

Pairing the remote control with the gimbal:

Please press the function button of the gimbal 7 times once the gimbal is turned on, the bluetooth light will flash alternatly in yellow and green and enter the pairing mode.

Make sure the gimbal is on the pairing mode before turning on the remote control to connect.



### During the pairing process:

a. The pairing can be completed in 3 seconds, after the gimbal bluetooth light stop flashing alternatly in yellow and green;

b. If the remote control is not paired within 30 seconds, the pairing will be cancelled;

c. Click the function button to cancel pairing;

d. Double-click the function button to clear the paired remote control and cancel pairing;

(And the paired remote control will be unavailable and need to be re-paired)

### ③ Function Button

**Single Press:** Switch the landscape and portrait modes

**Double Press:** Recenter the gimbal

**Triple Press:** Inception (Auto rotation)

### ④ M Button (Gimbal Working Mode)

**Single Press:** Pan&Tilt Follow

**Double Press:** Pan Follow

**Triple Press:** All Lock

**Quartic Press:** POV (All Follow)

**Long Press:** Switch the zoom in/out mode and gimbal tilt control mode (Zoom in/out mode only available in the app)

### ⑤ Navigation Buttons:

**Up/Down/Left/Right**

**Up/Down:**

- Tilt Control (Indicator light shows green)

- Control the image zoom in/out (Indicator light shows blue and only available in the app)

**Left/Right:** Pan Control

### ⑥ Indicator Light


The indicator light shows green or blue in button operation. If no light shows, it means the remote control is not turned on or no battery.

**Green light:** Gimbal controlling


**Blue light:** Phone camera controlling


# Selfie Stick Tripod

Gimbal installation




Handheld mode





Desktop Mode



## Specifications

<b>Product Name</b>	Selfie Stick Tripod & Wireless Remote Kit	<b>Selfie Stick Tripod Unextended Size</b>	187.5*39.5*30mm
<b>Product Model</b>	RS01	<b>Selfie Stick Tripod Extended Length</b>	300mm
<b>Remote Control Weight</b>	10.5g	<b>Notice</b>	
<b>Remote Control Transmission Distance</b> (Straight line without stuck)	10 meters	The remote control is built with a button battery. When the battery is low or power off, the indicator light will not light up. Please open the back cover of the remote control to replace the battery.	
<b>Selfie Stick Tripod Weight</b>	127.5g		