## **OPERATING INSTRUCTIONS**

## MOJOGEAR

## **OPERATING INSTRUCTIONS**



Thank you for choosing this MOJOGEAR Swift tripod. Please read this manual before use.


For information in other languages, please visit:

www.mojogear.eu/manuals









#### SPECIFICATIONS:



Arca Swiss Quick Release Plate with 1/4" Screw



Folded Height: 42 cm



Weight: 1.4 kg



Minimum Height: 44 cm



Payload: 5 kg




Maximum Height: 175 cm



26 mm 4-section Aluminum

#### Ball head instructions:



Loosen the Ball and Pan Knobs to adjust the shooting angle. Please hold your camera or phone while adjusting the ball head.



Lock and unlock the Quick Release plate with the Lock





The anti-slip nail prevents your camera from falling off when adjusting the quick release plate.




on the quick release plate to your camera without any tools. If you want to screw it more tight, you can use a coin.


### **Tripod Instructions:**














# MOJO**GEAR**

MOJOGEAR develops high-quality products for smartphone filmmakers, mobile creators and everyone else who wants to get the most out of their phone or camera. MOJOGEAR is proudly based in The Netherlands.

If you have any questions or feedback, please let us know at support@mojogear.eu. We'd love to hear from you!

MOJOGEAR BV, Nobelstraat 2-02, 5051 DV, Goirle, The Netherlands