
TELESIN Hero 9电池充电器



使用指南

简介

Hero 9 电池充电器需配合电源适配器使用,可同时为三颗 Hero 9 电池充电。充电器配备三个指示灯,分别指示对应 电池的充电状态。



使用

将电池插入充电器槽内(如图所示),连接充电器的Type C 接口与电源适配器。

1 指示灯 2 电池槽 3 Type C接口



指示灯

状态	指示灯
空载	绿灯常亮
充电时	红灯常亮
满电时	绿灯常亮

规格参数

型 号	GP-BCG-902
适用电池	Hero 9 电池
操作温度	5°C ~ 45°C
输 入	5V = 2A
输 出	4.4V 800mA×3

注意事项

- 1. Hero 9 电池充电器三路输出为4.4V 800mA,建议使用 输出参数达到5V 2A的电源适配器。
- 2. 充电器仅用于为Hero 9运动相机电池充电,请勿为其他 型号电池充电。
- 3. 使用时请将充电器平稳放置,并注意绝缘和防火。
- 4. 请勿用手触碰金属端子。
- 5. 若金属端子附着异物,请用干布擦拭干净。

www.telesin.cn


TELESIN Hero 9 Battery Charger



User Guide

Introduction

The Hero 9 Battery Charger can charge three batteries at the same time with USB adapter. The three LED indicators indicate the charging status.



1 LED Indicators 2 Battery Ports 3 Type C Port





Usage

Place the battery into battery ports as shown in the figure below. Connect the USB adapter to the Type C port.



LED Indicators

Status	LED Indicators
No batteries	Green LED is always on.
Charging	Red LED is always on.
Full	Green LED is always on.

Specifications

Model	GP-BCG-902
Supported Batteries	Hero 9 电池
Operating Temperature	5°C ~ 45°C
Input	5V = 2A
Output	4.4V 800mA×3

Note

- 1. Each output of the Hero 9 battery charger is 4.4V 800mA. It is recommended to charge with a 5V 2A USB adapter.
- 2. The Hero 9 battery charger is only compatible with Hero 9 batteries. DO NOT use the charger with other
- 3. Place the Hero 9 battery charger on a flag and stable surface when in use. Make sure the devices is properly insulate to prevent fire hazards.
- 4. DO NOT touch the metal terminals on the charger.
- 5. Clean the metal terminals with a clean, dry cloth if there is any noticeable buildup.

www.telesin.cn