

**MOJOGEAR MG-PB11**  
 Model: H9B  
 Batch 1  
 V2 - 27-10-2025

105.941 mm



**MOJOGEAR**  
**MINI GO**  
**10.000 mAh**  
**ALL-IN-1 POWER BANK**

**USER MANUAL**

Thank you for choosing this MOJOGEAR power bank. In this user manual you'll find all the relevant information to use your power bank.

For information in other languages, please visit:  
[www.mojogear.eu/manuals](http://www.mojogear.eu/manuals)

NL

FR

IT

PL

DE

ES

SE

TR



**Contents**

|  |  |
|--|--|
| <ol style="list-style-type: none"> <li>1. Overview</li> <li>2. Box contents</li> <li>3. Charging the power bank</li> <li>4. Charging your devices</li> </ol> | <ol style="list-style-type: none"> <li>5. Usage tips</li> <li>6. Technical details</li> <li>7. Safety instructions</li> <li>8. About MOJOGEAR</li> </ol> |
|--|--|

**1. Overview**

- 1 Display
- 2 USB-A port (output)
- 3 USB-C port (input/output)
- 4 Power button
- 5 Built-in Lightning cable (output)
- 6 Built-in USB-C cable (input/output)



**2. Box contents**

- Power bank
- Manual

**3. Charging the power bank**

- Connect the built-in USB-C cable to a USB-C charger. You can also connect a charging cable to the USB-C port.
- Depending on the charging speed, it can take 3 to 8 hours to fully charge the power bank.
- The digital display flashes while charging and shows 100% when fully charged.

**4. Charging your devices**

- Use the built-in cables or connect a charging cable to the USB-C or USB-A port.
- Charging speed depends on your device's battery and supported charging profiles.
- The display turns on during use and shows the approximate remaining capacity.

**5. Usage tips**

**Display Accuracy**  
 If the digital display seems inaccurate when you receive the power bank, follow these steps:

- **Fully discharge the power bank to 0%.** Do not charge it during this step.
- **When it reaches 0%, charge it to 100%.** Do not use the power bank to charge other devices while it is charging.

Repeat these steps two or three times if needed. After this adaptation, the display will show a more accurate remaining power.

**Temperature During Use**  
 When using the power bank, if the connected phone (or other device) has a low battery (below 70%), it is normal for the power bank to become slightly warm. At lower device battery levels, the power bank must deliver relatively higher output power, which can cause a small increase in temperature.

**6. Technical details**

|                             |   |   |
|-----------------------------|---|---|
| Size                        | 79.7 x 66.5 x 23.6 mm                       |  |
| Weight                      | 171g  |   |
| Capacity                    | 10000mAh / 38.5Wh                           |   |
| USB-C Input (Port & Cable)  | 5V=3A 9V=2A 12V=1.5A (Max 18W)              |   |
| USB-C Output (Port & Cable) | 5V=3A 9V=2.22A 12V=1.67A (Max 20W)          |   |
| USB-A Output                | 5V=3A 9V=2A 10V=2.25A 12V=1.67A (Max 22.5W) |   |
| Lightning Cable Output      | 5V=3A 9V=2.22A 12V=1.67A                    |   |

**7. Safety instructions**

- Do not use near explosive gases or flammable materials.
- Do not expose to excessive heat, such as sunshine or fire.
- Avoid abrupt changes in temperature.
- Do not use or store in humid or wet conditions.
- Do not throw, shake, vibrate, drop, crush or mechanically abuse the power bank.
- Do not burn or incinerate.
- Do not cover with objects which may affect the heat dissipation.
- Avoid contact with battery chemicals.
- Keep out of reach of children

**8. About MOJOGEAR**

**MOJOGEAR**

MOJOGEAR develops high-quality products for smartphone filmmakers, mobile creators and everyone else who wants to get the most out of their phone or camera.

MOJOGEAR is proudly based in The Netherlands.

**All MOJOGEAR products are covered by a 2-year warranty.**

If you have any questions or feedback, please let us know at [support@mojogear.eu](mailto:support@mojogear.eu). We'd love to hear from you!

60 mm      60 mm